

Read-a-Card software: Token license



Portable Read-a-Card software license in USB token format

Read-a-Card is a software utility that runs on a Windows PC and reads information from many types of contactless cards and tags. For instance, unique chip IDs and securely encoded card numbers can be read and logged to file, and automatically sent to other software or web applications using many different methods, including simply 'typing' the card ID (sometimes known as a 'keyboard wedge').

You will also need a separate, compatible contactless smartcard reader. Depending on the make and model of reader used, Read-a-Card can identify, read and decode many popular card technologies, including MIFARE Ultralight, MIFARE Classic, DESFire, iClass and/or HID Prox card numbers.

Note - this Read-a-Card token license is most suitable if you want the flexibility to move your reader(s) and/or software from one PC to another. The supplied ACR39T-A1 USB SIM reader contains a Read-a-Card SAM license and must be present when Read-a-Card is in use. Works with any compatible contactless reader.

Read-a-Card software for reading chip serial numbers and encoded card IDs from many types of contactless cards and tags. Useful for access control enrolment and the integration of RFID into new or existing systems. Includes advanced keyboard

wedge and web server modes, plus developer API. Licensed for use on any PC - requires a spare USB port and a separate, compatible contactless reader.

To buy, visit:

<https://www.smartcardfocus.com/shop/ilp/id~844/p/index.shtml>

This Product Briefing has been produced by Dot Origin Ltd, the smart card experts behind SmartcardFocus.com. If you have a query email sales@smartcardfocus.com or call us on +44 (0)1428 685250.

More about Read-a-Card

Read-a-Card is compatible with a wide range of contactless readers from different manufacturers, and can be used to identify different RFID cards and tags, test reader functionality and to enable the use of multiple readers on a single PC. It can integrate with other software and systems using a variety of methods and techniques.

Depending on the reader used, Read-a-Card can:

View a contactless smartcard's unique ID and automatically insert it into text input fields

Insert a custom prefix and suffix when performing RFID 'keyboard wedge' functions

Read and display MIFARE and DESFire card serial numbers (CSN) in hex and decimal and reverse decimal formats

Read HID iClass & Prox card IDs, with appropriate readers (including Corporate 1000)

Read MIFARE sectors, DESFire application files, and other data, optionally using a SAM for secure key storage

Work with multiple readers with the ability to detect and log unique reader IDs

Automatically log card IDs to file, with time stamp and reader ID

De-duplicate repeated card reads

Decode NFC tags and smart poster data

Automatically launch software applications and/or custom URLs on each card read

Additional developer features include:

Full integration with other software using Windows messaging API

Read-a-Card web server for kiosk integration

Plug-in capabilities to add any further functionality

Read-a-Card also provides the ability to decode customer-specific card numbering formats stored on either MIFARE, DESFire or iClass cards, through the use of software plug-ins and hardware security modules (SAMs) for holding keys and other sensitive data. Using this mechanism, Read-a-Card can be enhanced to be able to read a site-specific format and return the relevant card ID data to other applications using its built-in keyboard wedge, file logging or direct integration APIs, without exposing the encoding scheme security data.

For further details, screenshots, videos and developer documentation please visit www.read-a-card.com

Compatible readers

Read-a-Card works with most contactless 13.56MHz smartcard readers that conform to the PC/SC 2.01 standard, as well as some additional non-PC/SC readers and other specialist devices. Below is a list of those readers that have been specifically tested, but if you have a different model then please use the free trial version on the Read-a-Card web site to check compatibility. Current and recommended models, available from our online store, are shown in **bold**:

Current and legacy **ACS** readers: ACR120S, ACR120U, ACR122U, ACR122T, ACR122S, ACR122L, **ACR1222L**, ACR1251U, **ACR1252U-DOT**, **ACR1252U-M1 SAM**, **ACR1255U**, ACR128U, **ACR1281S-C1**, ACR1281S-C8, **ACR1281U-C1**, ACR1281U-C8, **ACM1252U-Y3**, **ACM1252U-Z2**, **ACM1281U-C7**

Notes: Up to 10 ACR1255U readers can be connected simultaneously via Bluetooth, using the ACS driver/tools. The ACR1252U SAM supports SAM licensing.

Current and legacy **Omnikey** readers: **5021 CL**, **5022 CL**, 5023 CL, **5025 CL**, 5121, **5127 CK Mini**, 5321 V2, 5321 CL, 5321 CL SAM, 5321 CR, 5325, **5325 CL**, 5421, **5422**, **5427 CK**, 6321

Notes: Most Omnikey readers support e-licensing. Legacy iClass reading is supported on the 5021 CL only (plus previous 5321 models). Non-legacy iClass SE and Seos card reading is not currently supported, and will require an Omnikey 5023 when released.

Current and legacy **SCM/Identiv** readers: SCL010, SCL011, **SCL3711**, SCM3712, SDI010, SDI011, uTrust/Cloud **3700F**, 4700F, **4701F**, **4711F**

Current and legacy **Sony** readers: RC-S320, RC-S330, **RC-S380**

Legacy **Gemalto** readers: IDBridge CL3000 (Prox DU), IDBridge CL300 (Prox SU)

Legacy **Gemini 2000** readers: GemTAG x1010IP

Legacy **Cherry** readers: Smartboard Twin G83-6675

Manufacturer:Read-a-Card